



**Sblocco a chiave
DIN per R18/R30/
R40**



**Release with key and
DIN lock for R18/R30/
R40**

**Not-Entriegelung mit
Schlüssel und DIN
Schloss für R18/R30/R40**

**Déverrouillage avec
clé et serrure DIN
pour R18/R30/R40**

**Desbloqueo con llave
y cerradura DIN para
R18/R30/R40**

R30/R40:



**PER SBLOCCARE:
TO UNLOCKING:**















fig.6



**PER BLOCCARE:
TO LOCKING:**

fig.7





**PER SBLOCCARE:
TO UNLOCKING:**









fig.5



**PER BLOCCARE:
TO LOCKING:**






fig.6